HiPSTER[®]6

A flexible **bipolar** HiPIMS pulser for the latest generation of coatings



HiPSTER BiPolar 6 HiPIMS Pulser

Our HiPSTER BiPolar HiPIMS units belong to a new generation of HiPIMS technology. They are designed by experts in the field with an excellent track record of plasma process development and thin film deposition in order to generate robust and repeatable HiPIMS processes.

With the new ultra-fast switching technology and extended HiPIMS pulse control the HiPSTER BiPolar is a perfect tool when developing and running state-of-the-art HiPIMS processes. Also, upgrading your existing magnetron system to HiPIMS has never been easier. The HiPSTER BiPolar can be connected either to two existing DC power supplies (positive and negative output) or to our tailor-made HiPSTER DC units.

FEATURES

- Bipolar operation provides ion acceleration without the need of substrate biasing
- Stable and robust discharge process (constant voltage and no unwanted oscillations)
- Can be triggered externally (multiple power supplies)
- New switching technology allowing HiPIMS pulsing frequencies up to 10 kHz
- Tested using a wide range of magnetrons and processes (incl. reactive HiPIMS)
- Add Ionautics' reactive process control for increased stability and higher deposition rate

APPLICATIONS

- Hard coatings: Smoother and denser elemental as well as reactively deposited compound coatings, which result in increased hardness, reduced corrosion, and less friction
- Optical coatings: Increased optical properties
 through smoother interfaces and denser structures
- Diffusion barriers: Better performance through increased coating density
- Electrical coatings: Improved conductivity enabling reduced coating thickness and reduced heat load.
 Also increased isolation in the case of insulators can be obtained
- 3-D coatings: Uniform film coverage on complex shaped substrates





General Output Specifications


Output Average Power:	≤ 6000 W
Regulation Modes:	Voltage, Current,
	Power, Pulse current
Pulse Frequency:	50 to 10 000 Hz*
Arc control - reaction time:	< 2 µs

* External triggering has an extended range; contact lonautics for more details.

Negative Pulse Specifications		
Output Peak Voltage:	≤ 1000 V	
Output Peak current:	≤ 600 A	
Pulse Duration:	3.5 µs to 1000 µs	


Positive Pulse Specifications	
Output Peak Voltage:	≤ 300 V
Pulse Duration:	1.5 µs to 500 µs
Pulse Delay:	1.5 µs to 500 µs**

** From end of negative pulse




Dimensions	
Size:	19" rack (3U) 135 mm (H) x 483 mm (W) x 390 mm (D)
Weight:	17 kg

Environmental Specifications	
Operating Temperature:	+5°C to + 40°C
Storage Temperature:	-25°C to +55°C
Relative Humidity:	max 85% non-condensing
Air Pressure:	80 kPa to 106 kPa
Cooling:	Air Cooling
Pollution degree:	2 (or better). Cooling air must normally be free of corrosive vapors and conductive particles.
Norms:	CE certified



Bipolar operation with short delay (1.5 µs) between negative and positive pulses.



Bipolar operation with long delay (140 µs) between negative and positive pulses.



DANIEL LUNDIN Professor

Expert in the field of HiPIMS processes and magnetron sputtering with focus on deposition processes and process characterization.



ULF HELMERSSON Professor

Expert in the field of physical vapor deposition, such as magnetron sputtering and HiPIMS processes with focus on material science.



CONTACT>>>>

RAFAEL SANCHEZ Global Sales Manager

In charge of sales and marketing worldwide. 10 years of experience in thin film deposition using magnetron sputtering.

Tel: +46-704 39 76 76 E-mail: rafael.sanchez @ionautics.com

SWEDEN: LINKÖPING: STORA TORGET 3, 582 19 LINKÖPING, SWEDEN PITEÅ (POSTAL AND SHIPPING ADDRESS) KABELGATAN 9B, SE-943 31 ÖJEBYN, SWEDEN STOCKHOLM: STRANDVÄGEN 1, 114 51 STOCKHOLM, SWEDEN USA: POSTAL ADDRESS: 19924 163RD AVE NE WOODINVILLE WA 98072 USA

